



Vector Skynode & non-Skynode | SB120 | 2.3.0.74

General

- Fixed heating issue
- Fixed SBP not charging to full capacity
- Fixed cycle count resetting after update
- Added cell temperature monitoring when charging
- Added new error mode

SB120 update is available via QBase Tactical as usual.

The process of updating the SB120 is described in the user manual (latest version is in the default installation directory `documents/QBase/Manual/Vector_Scorpion`).